

Moving Your Treadmill to Another Location

2003 Models:

1. Take screws out of back of console and unplug the console cable (black with multi-colored wires at plug.)
2. Remove bolts on top of console that holds it onto masts. Remove console.
3. Remove bolts at bottom of console masts and lift off masts being careful not to damage console cable.

Important: You will need something to tie around the deck and the base of the treadmill to hold them together.

Now you are ready to move your treadmill.

2001, 2002 Models:

1. Remove bolts from mast posts under each handlebar.
2. Remove console back plate and unplug the console cable (gray with multi-colored wires at plug. You may need to cut zip tie.)
3. Of the 3 screws on the front top of the mast post, loosen only the middle screw, which is the one that stands out from the others. Now you can proceed to step 4.
4. Slide console and handlebars up and set aside.
5. On the front side of the treadmill, take out front bolt, toward bottom.
6. Take bolts out from side of mast posts, near bottom.

At this point you should be able to fold the mast posts down and level the deck. Important: You will need something to tie around the deck and the base of the treadmill to hold them together.

Now you are ready to move your treadmill.

2000 Models:

1. Remove lower bolts from handlebars
2. Remove console back plate and unplug the console cable (gray with multi-colored wires at plug. You may need to cut zip tie.)
3. Loosen the 3 middle screws on the front side of the mast post that hold the handlebars in place.
4. Slide console and handlebars up and set aside.
5. On the front side of the treadmill, take out front bolt, toward bottom.
6. Take bolts out from side of mast posts, near bottom.

At this point you should be able to fold the mast posts down and level the deck.



You will need something to tie around the deck and the base of the treadmill to hold them together.

Now you are ready to move your treadmill.