

Calibration New Style Console

Determine Model # and refer to CALIBRATION CHART on pages 28-31. The characters appear in the CONSOLE windows as described below during calibration.

To change any of the settings, use the SPEED +or - button.

1. Insert pencil (eraser end in the hole on back of console.
2. Press reset 2 times (with pencil) until LCD shows CL21 in the time window.
3. Press ENTER. CL22 displays in TIME window and __ mph in the SPEED window.
4. Press ENTER. CL23 displays in TIME window and __ in the SPEED window.
5. Press ENTER. CL24 displays in TIME window and __ in the SPEED window.
6. Press ENTER. CL25 displays in TIME window and __ in the SPEED window.
7. Press ENTER. CL26 displays in the TIME window and __ in the SPEED window.
8. If you get the letter "E", press ENTER.
9. Press ENTER. The time window will show SS. Push the STOP/START button.
10. Push the ENTER button and the Treadmill will start.

WARNING: Do not stand on or touch the treadmill during calibration.

11. When the treadmill belt stops, push the POWER button 2 times. If the letter "F" appears in the SPEED or INCLINE window, the treadmill is indicating a failure in the SPEED or INCLINE during calibration. Call KEYS FITNESS.