How To Remove Lube Belt Msge – Horizon Model 5.1, 7.1

Hold down the stop and speed up buttons for 5 secs.