

Resistance Does Not Change



Date Prepared: 4/16/2013	Models Affected: R40 (RB151), U40 (CB158)
-----------------------------	--

If the unit's resistance does not change during a workout program or when the user tries to adjust it manually, the console may be set to the wrong frame type (R40i or U40i).

Verify and correct the model type in the Engineering mode – see the console service manual for instructions.

Revision Date: 7/13/2018 | Revised by: EM