

Pairing Passport Player 2.0 via Hotspot



Prepared by: Sophia Her	Date Prepared: 8/28/2018	Effective Date: 8/29/2018
----------------------------	-----------------------------	------------------------------

If the customer does not have home Wi-Fi, please follow these instructions to pair the Passport Player 2.0 to the equipment console using a Hotspot.

Touch Screen Consoles

1. Set up your Passport Player-compatible cardiovascular equipment per the instructions provided with the equipment.
2. In the setup menu for Passport Player, select Network and press the **Wi-Fi Hotspot** button.
3. A pop-up window with the SSID and password will appear on the screen.
4. Go to your console and follow the steps in your Owner's Manual for connecting your console to the internet via Wi-Fi.
5. When the option comes up to select a Wi-Fi network, select the network "Passport Connect" and input the SSID and password obtained from your TV screen.
6. This will connect the Passport Player directly to your cardiovascular console.

If unable to connect, restore factory default for both devices and repeat steps 1-5. Factory reset is required every time if the issue occurs at a store.

Non-Touch Screen Consoles

Note: A device with access to Wi-Fi is required for this process

1. Select the **Edit a User** button on the cardiovascular console.
2. Press and hold the **Wi-Fi** button for 3-5 seconds.
3. Select the preferred time zone and press the **Enter** button.
4. Go to the Wi-Fi device and connect to the equipment network (Note: Network name will vary by model. See Owner's Manual).
5. Open an internet browser and add the following URL: <http://10.10.100.254/> (Note: It will only work when the Wi-Fi device is connected to a console, because it communicates directly with the console Wi-Fi module).
6. In the setup menu for Passport Player, select Network and press the **Wi-Fi Hotspot** button.
7. A pop up window with the SSID and password will appear on the screen.
8. Go back to the Wi-Fi device and input the SSID and password obtained from the Passport Player.
9. Reconnect the Wi-Fi device to the Passport Player and click **Next**.
10. Press the **Refresh** button on the TV screen for the device to appear on the screen.
11. This will connect the Passport Player directly to your cardiovascular console.

If unable to connect, restore factory default for both devices and repeat steps 1-9. Factory reset is required every time if the issue occurs at a store.