


END OF LIFE

CT9500

CROSSTRAINER

CT95-0100-15

S/N CTG100000-CTG103197




Service Manual M051-00K61-B014
Operator Manual M051-00K20-B190
Installation Instructions M051-00K20-B188
Hardware Kit AK61-00050-0000

Optional: Chest Strap
Small: SK40-00045-0002
Medium: SK40-00045-0003
Large: SK40-00045-0004


CT9500 Cross-Trainer Drive Belts and Alternator

CT95-0100-15




CT9500 Cross-Trainer Console Support Assembly

CT95-0100-15




CT9500 Cross-Trainer
Console Assembly

CT95-0100-15




CT9500 Cross-Trainer Crank Arm w/Roller Assembly

CT95-0100-15





CT9500 Cross-Trainer Crankshaft Assembly AK61-00157-0002

CT95-0100-15



CT9500 Cross-Trainer Final Frame Drive Linkage Assembly


CT95-0100-15



CT9500 Cross-Trainer


Anti-Lift Bracket and Outer Pedal Covers

CT95-0100-15




CT9500 Cross-Trainer Battery, Brackets, and Frame Cover

CT95-0100-15



CT9500 Cross-Trainer Clevis and Front Frame Covers

CT95-0100-15




CT9500 Cross-Trainer Pedal Lever Assembly

CT95-0100-15


Left Pedal Assembly: GK61-00002-0005

Right Pedal Assembly: GK61-00002-0006




CT9500 Cross-Trainer
Rocker Arm Covers

CT95-0100-15




CT9500 Cross-Trainer Rocker Arm Assembly

CT95-0100-15



CT9500 Cross-Trainer Rear Drive Shrouds w/Decals

CT95-0100-15



CT9500 Cross-Trainer Upper Arm/Heart Rate Assembly

CT95-0100-15

