

END OF LIFE

LF Cross-Trainer
General Assembly

X30-0000-01

120V Dom. Eng/Eng

CONSOLE ASSEMBLY
REX2AXQ

GERMAN CONSOLE ASSEMBLY
REX2CTB

CONSOLE DECAL
REX2AV7

OVERLAY
REX2AXM

ENDCAP
REX21MV
ENDCAP SCREWS
REX0KC6

MODEL BADGE
REX2AVN

WATER BOTTLE
REX2B96
WATER BOTTLE HOLDER
REX21CV
SCREWS
REX0K4R

ACCESSORY TRAY: REX2AYF

HARDWARE BAG: REX2AZ8

TOUCH UP PAINT: 7967401

RECEIVER: REX21PV

TRANSMITTER: REX2B95

OPER. MANUAL: 7953401

FRONT
COMPONENTS

REAR
COMPONENTS


CLEVIS COVERS
FRONT
REX2AQU
REAR
REX2AQT


LF LOGO LABEL
REX2ARH

MOVEMENT ARMS
& HARDWARE

BLOCK
DIAGRAM

CABLES







LF Cross-Trainer **Rear Components**

X30-0000-01

120V Dom. Eng/Eng





RIGHT FRONT COVER (NOT SHOWN)

REX2AQ1

LEFT FRONT COVER (NOT SHOWN)

REX2AQ6

MAST COVER SCREWS (3 PER COVER)

REX0K4S

