




REF#	PART#	DESCRIPTION
AB1	70695	MAIN FRAME
B21	70624	SOCKET HEAD CAP SCREW
B22	15546	WASHER
B13	70633	NYLON NUT
B28	91652	LEVELER LOCK NUT
B29	84995	LEVELER
C11	70564	WATER TOP COVER
C12	70565	WATER BOTTOM COVER
C53	70602	PAN HEAD SCREW
C54	70570	MAST SLEEVE (JACKET)
C56	70604	PAN HEAD SCREW
AE1	70698	SUB PEDAL ARM (07 REV: 002-1858)
AE2	70700	LEFT PEDAL ARM (07 REV: 002-1859)
AE3	70701	RIGHT PEDAL ARM (07 REV: 002-1860)
AE4	INCL W/AXLE	PIVOT TUBE
E25	70690	PIVOT AXLE
E26	70692	BUSHING
E27	70596	BEARING
E28	70561	LEFT FOOTPLATE
E29	70562	RIGHT FOOTPLATE
E30	70556	PEDAL ARM COVER
E31	70662	NYLON WASHER
E32	70627	SOCKET HEAD CAP SCREW
E33	15053	WASHER
E34	15509	SPRING WASHER
E35	70609	PAN HEAD SCREW
E36	70602	PAN HEAD SCREW
E37	70636	NYLON NUT
E38	15543	WASHER
E39	93301	TEFLON WASHER
E40	92961	BEARING 6005ZZ
AG1	70548	RIGHT HANDLEBAR (ONLY AVAILABLE IN SLVR. FOR GRAY UNITS REPLACE BOTH SIDES)
AG2	70547	LEFT HANDLEBAR (ONLY AVAILABLE IN SLVR. FOR GRAY UNITS REPLACE BOTH SIDES)
AG3	70546	HANDLEBAR
G10	70563	HANDLEBAR GRIP
G11	NA	BRASS INSERTS NUT
G12	70623	SOCKET HEAD CAP SCREW
G13	70658	CURVE WASHER
G14	15509	SPRING WASHER
G15	70620	SOCKET HEAD CAP SCREW
AG4	70709	LEFT SWING ARM (07 REV: 002-1865)
AG5	70710	RIGHT SWING ARM (07 REV: 002-1866)
AG6	70711	UPPER ARM (07 REV: 002-1867)
G70	70557	SIDE COVER FOR PEDAL ARM
G71	70558	TOP COVER FOR PEDAL ARM
G72	70597	BEARING
G73	70664	NYLON NUT
G74	70663	WAVE WASHER
G76	92415	C CLIP S30
G77	70601	PAN HEAD SCREW
G78	70611	SOCKET HEAD CAP SCREW
G79	80086	WASHER

REF#	PART#	DESCRIPTION
G80	92950	NYLON NUT
G81	98353	BEARING 6002ZZ
G82	80095	SOCKET HEAD CAP SCREW
G83	15546	WASHER
G84	70598	BEARING
G85	000-0385	C CLIP R32
G86	97972	C CLIP R35
G87	70652	WASHER
G88	93558	C CLIP S15
G89	95623	SPRING WASHER
G90	70622	SOCKET HEAD CAP SCREW
AJ1	70706	RIGHT CRANK (07 REV: 002-1863)
AJ2	70707	LEFT CRANK (07 REV: 002-1864)
AJ3	70708	SUB CRANK
J10	91610	C CLIP S25
J11	70638	NUT
AL1	70704	FRONT STABILIZER (07 REV: 002-1861)
AL2	70705	REAR STABILIZER (07 REV: 002-1864)
L21	91652	LEVELER LOCK NUT
L22	84995	LEVELER
L23	70551	TRANSPORT WHEEL
L25	92950	NYLON NUT
L26	70616	PAN HEAD SCREW
L27	70567	RIGHT END CAP FOR FRONT STABILIZER (07 REV: 002-1896)
L28	70568	LEFT END CAP FOR FRONT STABILIZER (07 REV: 002-1897)
L29	70566	END CAP FOR REAR STABILIZER (07 REV: 002-1895)
L30	70613	SOCKET HEAD CAP SCREW
L33	70658	WASHER
AN1	002-1894	NE2000 COMPUTER (Only available in 07 REV version)
AN2	70712	READING BRACKET (07 REV: 002-1868)
N06	98111	CHEST STRAP
P01	70687	DC BRACKET
P02	70569	GRIP HR HOUSING
P03		GRIP HR PLATE
P04		PAN HEAD SCREW
P05		HEX NUT
P06	50065	END CAP FOR GRIP PLUSE
P07	70576	SENSOR WIRE
P09	70581	HEART RATE WIRE
P10	70582	HEART RATE EXTENDED LINE
P11	70684	SENSOR BRACKET
P12	70602	PAN HEAD SCREW
P13	70602	PAN HEAD SCREW
P14	70723	CONSOLE EXTENDED CABLE
P15	70584	CONSOLE CABLE
P16	30048	A/C ADAPTOR
P17	70600	PAN HEAD SCREW
P18	70632	NYLON NUT
Q01	70552	FRONT SHROUD
Q02	70555	RIGHT SHROUD
Q03	70553	LEFT SHROUD
Q04	70685	RIGHT ACCESS PANEL
Q05	70686	LEFT ACCESS PANEL

REF#	PART#	DESCRIPTION
Q20	70628	PAN HEAD SCREW
Q21	70603	PAN HEAD SCREW
Q22	70621	SOCKET HEAD CAP SCREW
Q23	70618	PAN HEAD SCREW
Q24	N/A	C CLIP
Q25	70605	PAN HEAD SCREW
Q26	70607	PAN HEAD SCREW
R01	INCL W/70591	AXLE
R02	70669	BEARING HOUSING RIGHT
R03	70670	BEARING HOUSING LEFT
R04	93298	BEARING 6204ZZ
R05	70591	PULLEY
R06	70587	MAGNET
R07	70599	DRIVE BELT
R17	70638	NUT
R19	92417	C CLIP S20
R20	93306	C CLIP R47
R21	93307	NUT
R22	70644	PIN
R24	70660	WASHER
R25	70610	SOCKET HEAD CAP SCREW
R32	70665	TRAY WASHER
AS1	70593	MAGNET UNIT
R26	33157	HEX NUT
R27	70630	HEX NUT
R28	70654	WASHER
R29	70619	EYE HOOK SCREW
R30	70689	EYE HOOK COVER
R31	70634	NYLON NUT
R35	80119	DC MOTOR
R34	70618	PAN HEAD SCREW
V05	70680	SHROUD DECAL (07 REV: 002-1893)
V11	70682	ASSEMBLY GUIDE
V12	70683	OWNER'S MANUAL
AZ1	70667	HARDWARE PACK
	70640	MAST HRDWRE