

CONSOLE CALIBRATION

- 1)** Turn power switch on. Hold down Stop/Enter button and incline up & down button at same time and insert safety key.
- 2)** Console will turn on and display will show “E-1” in the bottom window and 1 in the top window.
- 3)** Press the incline up button and the 1 in the top window will go to 2. Press the START button.
- 4)** Age display shows “0”, and the deck will move down to the lowest level. Press incline DOWN button to adjust the deck level to the lowest position then press the STOP button.
- 5)** Now press the START button, the age displays “15” and the deck will incline to the highest level. Press the incline UP button until the incline reaches the highest point (you will hear the motor stop running). Press the incline DOWN button two times, then press STOP. The incline calibration process is complete. Pull out the safety key and push back in. ERR-2 should not appear.