



XT175 Calibration

1. Remove tether cord. Press and hold the START and FAST buttons and put tether cord back on. Display will go into test mode. "SET" will blink in middle of screen.
2. Use "STOP" button to change from Km (Metric) to M (English).
3. Wheel size will be shown in the SPEED window. Use FAST or SLOW buttons to change. (2.50) Press START.
4. Minimum speed will be shown in the SPEED window. Use FAST or SLOW buttons to change. (0.5) Press START.
5. Max speed will be shown in the SPEED window. Use FAST or SLOW buttons to change. (10.0) Max elevation will be shown in the INCLINE window. Use UP or DOWN buttons to change. (14)
6. Press START. Unit will now auto-calibrate speed then incline. Unit will reset when it completes calibration.