



Z - 8 Calibration

Remove tether cord

Press and hold Mode and Start.

Replace tether cord

Display should go into test mode

Display flashes Set

Press Stop to toggle from Km. to M (shows in lower right hand window)

Press Start and adjust Roller Dia.

Press Start and adjust Min Speed.(if needed)

Press Start and adjust Max Speed (if needed)

WARNING - Do not stand on belt for next step.

**Press Start and unit will flash CAL and start the belt and incline calibration. This is automatic
Unit will shut down after it finishes.**

Unit is now ready.