

Replacing the 220 and 221 thumb control sensor covers

1. Remove the two 119 screws from the back cover of the thumb control sensor handles.
2. Pull apart the 220 and 221 thumb sensor covers
3. Unplug the 603 wire harness and the two pulse sensor wires from the two metal prongs.
4. Securely plug the 603 wire harness and thumb sensor wires into the new thumb sensor cover.
5. Reassemble the thumb sensor covers onto the action handle bar.
6. Repeat for other side.



