

Rev. A	LIVESTRONG	Control Number XXXXXXXXXXXX
Effective Date 11/23/2009	Out of Box: Misaligned Arm	Page 1/1
Revised Date 8/22/2017	Approved by Bill Baier	Prepared by Kevin Oeltjenbruns

DESCRIPTION

Follow these instructions to fix a pedal arm that is out of alignment when the Livestrong elliptical is taken out of the box. Adjust the bolt at the pivot block / pedal arm connection.

PROCEDURE

- 1) Use a Phillips screwdriver to remove the upper and lower pivot block covers (Figures A-D).
- 2) Loosen the bolt / nut revealed by removing the pivot block cover (Figure E).
- 3) Center the pedal arm roller so that the roller is making even contact with the roller track at all points in the roller path (Figure F).
- 4) Hand tighten the bolt / nut at the pivot block / pedal arm connection. **DO NOT** overtighten this bolt / nut.
- 5) Re-install the pivot block covers.
- 6) Repeat this procedure for the other side of the elliptical.



Figure A



Figure B



Figure C



Figure D



Figure E



Figure F