

LS625E & EX55 Error codes

<i>Symptom</i>	<i>Possible Cause</i>	<i>Test Procedure</i>	<i>Repair</i>
E1 Error	Failed Console Cable	Check Console Cable connections at the console, and at the DC motor if possible.	Replace console cable
	Failed DC Motor	Check DC motor voltages. Check wire connections.	If all wires look fine, and unit still displays E1 error, replace DC Motor and Console Cables
	Failed Console Set		If you replaced DC motor and Console Cables and unit still displays E1 error, then replace console.
E2 Error	Failed Console Set	Failed EEPROM (a chip on the board). Verify AC Adapter. The correct adapter is 6 volts.	Replace Console Set