

Troubleshooting Guide – Distance in Pause Mode



Date Prepared: 2/18/2013	Models Affected: S7100 Premier console (CEP234, CEP249)
-----------------------------	--

If a workout is paused while the console is still showing RPM, the distance reading on the console will continue to increase.

To prevent an inflated distance reading, decrease RPM to “0” before pressing Pause.