

	Troubleshooting Guide: RPM/Speed Readout	
Prepared by: Tanisha Cothrine-Evans, Emilie McWilliams	Date Prepared: 6/22/2017	Models Affected: Indoor Cycles

DESCRIPTION

Use the following table to troubleshoot an issue with speed readout on an indoor cycle.

Symptom	Possible Cause	Test Procedure	Repair
No speed readout on computer.	The sensor wire is not working.	Check the wire to make sure it is not damaged or severed.	Replace the sensor wire.
	The magnet is missing.	Check the flywheel to make sure that the magnet is present and secure.	Reattach or replace the magnet.
	The sensor is too far from the magnet. ¹	Check the distance between the sensor and the magnet. The distance should be less than 10mm (3/8"). For comparison, a standard pen is about 9mm wide.	Reposition the sensor closer to the flywheel.
	The computer battery is low.	Check the computer batteries.	Replace the computer batteries.

¹ This is frequently the cause of out-of-box speed readout issues.