


S7100 Lower Control Board LEDs



Incline DOWN – This LED should be lit any time that the elevation motor receives a signal to go down in elevation.

Incline UP – This LED should be lit any time that the elevation motor receives a signal to go up in elevation.

Power – This LED should be lit anytime that the unit has power.