



E3800HRT Fitness Bike TV BRACKET

ASSEMBLY GUIDE




TOOLS & PARTS INCLUDED




4mm L-Shaped Wrench
Quantity: 1




M5x12L Bolt
Quantity: 2



M8x10L Set Screw
Quantity: 1



M8x15L Bolt
Quantity: 4




500 South CP Avenue ▪ P.O. Box 280 ▪ Lake Mills, WI 53551
toll free 800.335.4348 ▪ phone 920.648.4090 ▪ fax 920.648.3373
www.visionfitness.com

©2007 Vision Fitness. All Rights Reserved. 8.07
AG18.53PRD
REV2


ASSEMBLY STEPS

TV BRACKET


1




2




3




4




5




6



7



8



(1) Remove the console mast cover from the console mast by removing the two screws in the console mast cover.

(2) Feed the coaxial cable and the TV power cable through the hole in the front of the console mast. Remove the protective plastic cover from the cables.

(3) Connect the TV power cable and the coaxial cable from the TV bracket with the TV power cable and the coaxial cable from the console mast. Be sure the cables are firmly connected.

(4) Attach the TV bracket to the console mast using four bolts (M8x15L). First insert one bolt on the left and one bolt on the right to help align all of the holes. Insert all four bolts before fully tightening. Insert one set screw (M8x10L) into the front of the console mast. Tighten with the 4mm L-shaped wrench.

(5) If mounting bolts are inserted in the TV, remove them from the back of the TV. If the TV uses the larger bolt hole pattern, remove the square metal plate from the TV bracket.

(6) Attach the TV power cable and coaxial cable from the TV bracket to the TV. Be sure cables are firmly connected.

(7) Attach the TV to the TV bracket using the four TV mounting bolts that were removed from the TV. Insert all four bolts before fully tightening.

(8) Attach the TV bracket cover to the TV bracket using two bolts (M5x12L). Insert both bolts before fully tightening.