

BELT STOPS WHEN STEPPED ON

- 1) When you get to the site, be sure to ask the customer what problem he's having.
- 2) Get on the treadmill to verify the problem the customer is having.
- 3) Remove the hood of the treadmill and walk on unit again.
- 4) If motor is rotating:
 - a) check if walking belt is loose (must be able to lift no more than 3`` off deck)
 - b) check to see if drive belt is rotating. If not, tighten drive belt.
 - c) check to see if roller shaft is rotating. If not make sure (b) above was done.
 - d) check to see if front roller flywheel is rotating. If it is and the roller shaft is not, the front roller is faulty. Replace front roller.



Copyright © 2009 Techmotion