

Adjusting the Levelers on the T4 and T6 Treadmills

Tool Required:

- 17mm Wrench

Procedure:

If you experience excessive bounciness at zero percent elevation, the levelers on the main frame may need to be loosened so they sit securely against the elevation frame. Please follow these steps:

1. Turn the power on and insert the safety key.
2. Press start and raise the elevation to 12%.
3. Pull the safety key out.
4. Take the 17mm wrench and twist the leveler nut counterclockwise to loosen it so the leveler threads are exposed up to .25".
5. When the elevation is at 0%, the rubber leveler should be compressed against the elevation frame.

