



SERVICE

XT 8 Calibration

Distance	Time	Calories	
(A)	(B)	(C)	
(D)			
(E)	(F)	(G)	(H)
Program	Incline	Pulse	Speed

- 1) Remove Tether Cord. Depress Start and Fast Buttons. Replace Tether Cord.
Display should go into test mode. After testing LED's window (D) will Flash SET
- 2) Roller Size will be displayed in window (H) Adjust with Fast/Slow. 2.50
Grade Return On will be displayed in window (E) Adjust with Up/Down. On
M/Km will be displayed in window (H). Change with Stop button Miles/Kilometers

WARNING - DO NOT STAND ON BELT FOR NEXT STEP

- 3) Press Start
- 5) P 1 will be displayed in window (E) Adjust with Up/Down. P 1
(tether cord message)
0.5 (Min Speed) will be displayed in window (H) Adjust with Fast/Slow
- 6) Press Start
- 7) 14 will be displayed in window (F) Max Incline. Adjust with Up/Down 14
10.0 will be displayed in window (H) Max Speed. Adjust with Slow/Fast 10.0
- 8) Press Start. Unit will now auto-calibrate speed then incline. Unit will reset when it
completes calibration.