

Service Setting

Enter the service Engineer Mode

Switch the power on, press and hold INCLINE UP and DOWN and STOP/ENTER 3 buttons then insert the safety key to enter the ENGINEER MODE. Time/Distance display shows “1” and blinking.

Set and display the manufacture date and software version

Press START button, Time/Distance display shows the manufacture YEAR, Heart Rate display shows manufacture MONTH, Calories display shows manufacture DATE. Speed display shows software version. The service engineer can adjust the manufacture date by pressing Incline Up and Down button follow the blinking display then press Enter after each adjustment to record the service date if necessary. After all the adjustment done, press Enter again to exit the Engineer Mode.

Incline Calibration

Enter Engineer mode.

Press Incline Up and Down button till the Time/Distance display shows “2” to enter the Incline Calibration Procedure.

Incline Level display shows “0”. Press Incline up and Down button to bring the deck to horizontal position then press STOP/ENTER button to set the L0 level.

After set the L0 level, Incline Level display shows “15” and the treadmill will start incline. Wait till the treadmill stop at the highest position then press STOP/ENTER twice to set the L15 level and exit the engineer mode.

Speed Calibration

Enter Engineer mode.

Press Incline Up and Down button till the Time/Distance display shows “3” to enter the Speed Calibration Procedure.

Speed display shows “0.5”mph or “0.8”kph. Press Speed Up and Down button to adjust the actual speed and measure the belt speed by speed meter then press STOP/ENTER button to set the lowest speed.

After set the lowest speed, Speed display shows “10”mph or “16”kph then treadmill speed will start increase. Wait till treadmill stop increase the speed, measure the belt speed by speed meter and press Speed Up and Down to adjust the actual speed then press STOP/ENTER button twice to exit the Engineer mode.

SLEEP / DISPLAY Mode

When the power is ON the computer will automatically enter SLEEP MODE if it is left idle for 3 minutes without receiving any input. Press any button to return to POWER ON status when the computer is in the SLEEP MODE.

To cancel the SLEEP MODE feature using the DISPLAY MODE and always keep the console display on, pull out the safety key, press and hold the SPEED UP and DOWN buttons, insert the safety key to power on the treadmill. After one short beep sound the TIME LED window will show “ON” (SLEEP MODE feature on) or “OFF” (SLEEP MODE feature off). Press the INCLINE UP and DOWN buttons to switch between “ON” and “OFF” then press STOP/ENTER to save the setting and return to POWER ON mode.

Set sound on/off

Power on and pull out the safety key, press and hold the SPEED UP and DOWN buttons, insert the safety key to power on the treadmill. After one short beep sound the PULSE/INCLINE level display window show “1” and blinking. Press the INCLINE UP and DOWN buttons to select show “2” then press START button, computer will show “ON” or “OFF”, press INCLINE UP and DOWN to select between on/off then press STOP/ENTER button twice return power status.