

SOLE TREADMILL INCLINE TEST

1. Unplug and turn off treadmill




2. Remove the right handlebar covers




3. Disconnect the upper harness from the middle harness

SOLE FITNESS CONNECTED UPPER AND MIDDLE HARNESS



SOLE FITNESS UPPER AND MIDDLE HARNESS DISCONNECTED




4. Plug treadmill into power socket and turn power switch on




5. Test 'incline down' function. Using a paper clip, connect pins 2 and 4. Incline should start going down, if on an incline.

SOLE FITNESS INCLINE DOWN TEST



6. Test incline up function. Using a paper clip, connect pins 2 and 3. Incline should start going up, if not already all the way up.

SOLE FITNESS INCLINE UP TEST



7. If steps 5 and 6 above are successful, the controller, wiring harness and incline motor are functioning properly. Replace the console.